




Internal interchange Out-of-station interchange Through service End of Line

T1 North Shore & Western Line	T2 Leppington & Inner West Line	T3 Liverpool & Inner West Line
T4 Eastern Suburbs & Illawarra Line	T5 Cumberland Line	T6 Bankstown Line
T7 Olympic Park Line	T8 Airport & South Line	T9 Northern Line

M1 Metro North West & Bankstown Line	M2 Metro Western Sydney Airport Line	M3 Metro West Line
--------------------------------------	--------------------------------------	--------------------

L1 Dulwich Hill Light Rail	L2 Randwick Light Rail	L3 Kingsford Light Rail
L4 Westmead & Carlingford Light Rail	L5 Parramatta and Olympic Park Light Rail	

Sydney Metropolitan Rail System

Created by Xing Lin / crossinglights.net / 2025

